

E-bike: How to guide

Wellington, Dunedin, Tauranga, Hamilton, Christchurch

1. Bike pack and safety gear

- a. Book an e-bike through Fleet Management
- b. The pannier bag contains a helmet, vest, bike lock, first aid kit and a hard copy of the factsheet
- c. Pannier bags are on the bike [1]




2. Starting the e-bike

- a. You do not need a key to turn on the bike, just push the start button [2]
- b. The pedal assist will kick in after the second pedal rotation [3]



3. Battery and power levels

- a. The 'batter' level indicates how much battery is left. Once the battery hits zero, the pedal assist function will cease [4]
- b. The 'range' indicates the level of power assist with High being full power, Normal moderate assist and Eco minimal. We suggest starting on eco, you can choose by using up/down button on handlebar by bell [6]
- c. The power assist cuts out at 25km per hour
- d. The bikes maximum range on full battery is 80km on Eco mode the more hills you go up the more battery required.



4. Turning off the e-bike

- a. Turn off the bike [7] (Make sure you don't leave bike on while unattended)
- b. Lock the bike to something secure



5. Returning the e-bike

- a. Turn off the bike [8] and plug into charger



Enjoy your ride! If you have any questions please contact your cycle champions.